
Blue lines = "New" Class B Airspace"
Green lines = "Old" Class B Airspace
DO NOT USE FOR NAVIGATION
70
50
75
75
65
50
50
45
45
70
80
80
60
45
80
15
93