
Blue lines = "New" Class B Airspace"
Green lines = "Old" Class B Airspace
DO NOT USE FOR NAVIGATION
50
80
70
80
161
15
DO NOT USE FOR NAVIGATION